


Euramax Canada, Inc. Snow Guard Guidelines

Euramax Canada, Inc. snow guards are devices that are attached to the roof structure in order to provide uniform retention and control the snow from avalanching in large sheets. The snow guards need to be applied in sufficient quantity according to a prescribed pattern in order to be effective. Snow Guards are intended to reduce snow movement and provide for a controlled melt and breakdown of the snow mass into smaller sections. Snow guard placement will vary from region to region and will be influenced by roof pitch, the lengths of roof runs and roof features. Local installation customs may not be the best guide for placement. Additional information can be found in Sheet Metal and Air Conditioning contractors' National Association (SMACNA) architectural sheet metal manual. Ultimately a qualified professional should determine placement.

SNOW GUARD PATTERN REQUIREMENTS TYPICAL FOR SHINGLED ROOFING

Euramax Canada will provide a custom snow guard pattern recommendation. Please contact us at 800-461-5706, for your custom layout. Snow guard patterns provided by Euramax Canada are only recommendations. Actual snow guard patterns should be approved by a licensed architect.



Snow guards should never be placed beyond the bearing wall on an extended roof section. This can result in ice damming and cause structural damage.

Euramax Canada, Inc. warrants that the products it manufactures shall be free from material defects. Should any of the products prove defective, the obligation of Euramax Canada, Inc. under this warranty shall be limited to replacement of the defective product or at our option the cost of the product originally shipped by Euramax Canada. This warranty is expressly in lieu of all other warranties expressed or implied including the warranties of merchantability and fitness for a particular purpose. There are no warranties, which extend beyond the description on the face hereof. Euramax Canada, Inc. in no event, whether claim is based on warranties, contract negligence or otherwise, is liable for incidental or consequential damages.

Euramax Canada, Inc. will not be responsible for misapplication or modification of product, incorrect material or defects that were obvious at time of installation. Any consequential damage, schedule delays, additional labor, and or equipment rental costs will not be Euramax Canada responsibility. Any Euramax Canada product warranty claim is limited solely to Euramax Canada, Inc.